






Installation manual

ACO Access Covers

UNIFACE Assist GS FR

ENG	Installation Manual	EST	Paigaldusjuhend
GER	Installationsanleitung	LAV	Uzstādīšanas instrukcija
FRA	Instructions d'installation	LIT	Montavimo instrukcija
ESP	Manual De Instalación	POL	Instrukcja montażu
POR	Manual de Instalação	BUL	Инструкции за инсталация
ITA	Manuale d'installazione	HUN	Beépítési útmutató
NLD	Installatiehandleiding	RUM	Instructiuni de instalare
CZE	Instalační manuál	HRV	Upute za ugradnju
RUS	Инструкция По Установке	SLV	Navodila za vgradnjo
SWE	Installationsanvisning	SRP	Preporuka za ugradnju
NOR	Installasjons Manual	TUR	Montaj kılavuzu
FIN	Asennusohje		
DAN	Installationsvejledning		




ACO Access Covers UNIFACE Assist GS FR


Order information



Clear opening (A x B)	External dimensions (C x D)	Frame height	Cover depth	Space for final floor	Load class (EN 1253)	Weight	E	El	Part No.
[mm]	[mm]	[mm]	[mm]	[mm]		[kg]			GS
600 x 600	726 x 726	89	70	15	M125	52	E120	El120	447939
800 x 800	926 x 926	89	70	15	L15	76	E120	El120	447940
1000 x 1000	1126 x 1126	89	70	15	L15	100	E120	El120	447941
600 x 600	726 x 726	89	110	15	N250	52	E120	El120	447943
800 x 800	926 x 926	89	110	15	M125	75	E120	El120	447944
600 x 800	726 x 926	89	70	15	M125	62	E120	El120	447945
800 x 1000	926 x 1126	89	70	15	L15	87	E120	El120	447946
600 x 750	726 x 876	89	70	15	M125	59	E120	El120	447949
600 x 900	726 x 1026	89	70	15	M125	66	E120	El120	447950
900 x 900	1026 x 1026	89	110	15	M125	86	E120	El120	447951
600 x 1000	726 x 1126	89	70	15	M125	72	E120	El120	447952
750 x 750	876 x 876	89	70	15	L15	69	E120	El120	447953






Notes:




A large grid of small squares, intended for taking notes. The grid consists of 20 columns and 30 rows of squares, totaling 600 squares. The lines are thin and grey.

























ACO. we care for water



Every ACO product supports
the ACO WaterCycle



-
- ACO Access Covers UNIFACE
Fire Resistance (FR)
 - ACO Access Covers PAVING
Fire Resistance (FR)
 - ACO Access Covers SOLID
Fire Resistance (FR)
 - ACO Access Covers SERVOKAT GD
Fire Resistance (FR)
-



ACO Industries k.s.

Havlickova 260
582 22 Pribyslav
Czech Republic

www.aco-accesscovers.com

NM24089 ACO Access Covers UNIFACE Assist GS FR Manual/EN/Q4/24